



SPRAYING/EXTRUSION VALVES ACCESSORIES



PRECISION PRESSURE REGULATOR LRP-1/4-4 WITH PRESSURE GAUGE

DP-K-002-000070

The precision pressure control valve is used for fine adjustment of the pneumatic inlet pressure for the spray air at the spraying valve. With it, the spraying behavior can be optimally adapted to the individual framework conditions, such as the applied medium, distance and environment.

TECHNICAL DATA

| | |
|---------------------------------|------------------|
| Connection thread | G 1/4" |
| Flow rate | 2000 l/min |
| Pressure control range | 0.05–4 bar |
| Length x width x height | 143 x 58 x 15 mm |
| Incl. mounting bracket HR-1/4-P | |

SEALING SCREW

DP-K-003-000105

Sealing screw incl. all seals between needle and nozzle.

▶ ▶ ▶ SVEP, SVPP, EV40, EV50

SEALING BUSH

DP-K-003-000109

Sealing bush incl. all seals between needle and nozzle.

▶ ▶ ▶ SVEP, SVPP, EV40, EV50

PRESSURE TRANSMITTER 1/8"

DP-K-003-000116

Pressure transmitter 0–50 bar for monitoring the process-relevant medium pressure.

▶ ▶ ▶ SVEP, EV40, EV50



SPRAYING/EXTRUSION VALVES ACCESSORIES

MAGNETIC VALVE

DP-K-003-000102 // for SVEP
DP-K-003-000113 // for EV40
DP-K-003-000115 // for EV50

Solenoid valve 5/2 ways for 24 V, incl. plug.

▶ ▶ ▶ SVEP, EV40, EV50

RASTER NEEDLE LOCK SPRAYING VALVES

DP-K-003-000100 // for SVEP
DP-K-003-000101 // for SVEP, with sensing
DP-K-003-000106 // for SVPP
DP-K-003-000107 // for SVPP, with sensing

Lock for easy adjustment of the needle stroke.

▶ ▶ ▶ SVEP, SVPP

RASTER NEEDLE SENSING

DP-K-003-000108 // for SVSV, complete
DP-K-003-000110 // for SVKA/SVKAHD, complete

▶ ▶ ▶ SVSV, SVKA, SVKAHD

VALVE HEATING

DP-K-003-000091 // for SVPP/SVEP
DP-K-003-000094 // for EV50

Heater for mounting on automatic valves.
Incl. pre-assembled cable with plug, heating element and temperature sensor.

▶ ▶ ▶ SVPP, SVEP, EV50

HEATING HOSE DKR 3/8"

DP-K-003-000092 // L = 1 meter



SPRAYING/EXTRUSION VALVES ACCESSORIES

MATERIAL SEAL SET

DP-K-003-000104 // for SVEP/SVPP/EV40/EV50

All seals that come into contact with the medium.

▶▶▶ SVEP, SVPP, EV40, EV50

INSULATING PLATE

DP-K-003-000090 // for SVPP/SVEP

DP-K-003-000093 // for EV50

▶▶▶ SVEP, SVPP

AIR VALVE

DP-K-003-000103 // for SVEP, complete

▶▶▶ SVEP